

Period Styles in American Architecture



Primed Decorative Wood Moulding

Gesso Coating is a primer long used in oil painting to ensure the smoothest possible surface on the canvas. Gesso Coating offers:

- High hide: Wood grain and characteristics, finger-joints and edge laminations which commonly show through with water-based primers are hidden.
- Smooth texture: "Orange peel" texture commonly seen in mouldings with water-based primers is eliminated.

Installation and Finishing Tips:






Mouldings should be pre-drilled before nailing. This prevents splitting and cracking. Counter-sink all nail heads and touch up with acrylic latex wood filler. Simply use a latex primer and one or more coats of oil or water based paint. When using paints follow the manufacturer's instructions.

Available From:



© 80M 1/2006 Ornamental Mouldings Ltd. OML-K








Cornices

	PROJECTION 27/32" (56mm) DEPTH 2 1/4" (57mm)	OML34G 3 7/64" x 3 1/16" Colonial
	PROJECTION 39/16" (90mm) DEPTH 3 9/32" (88mm)	OML36G 9/16" x 4 31/32" Colonial
	PROJECTION 3 1/2" (82mm) DEPTH 3 23/32" (98mm)	OML37G 2 1/32" x 5 1/32" Dentil/Federal
	PROJECTION 3 13/16" (97mm) DEPTH 3 1/16" (94mm)	V28RTO 2 9/32" x 5 1/2" Ribbon & Ivy
	PROJECTION 3 7/8" (98mm) DEPTH 3 3/8" (94mm)	V5026D 2 9/32" x 5 1/8" Versailles






Baseboards

	OML24G Colonial 1/2" x 4 7/32"		OML30AG Victorian 9/16" x 5 15/32"
	OML25G Colonial 9/16" x 5 15/32"		V5022D Versailles 3/4" x 4 17/32"
	OML 26G Tudor 9/16" x 5 15/32"		OML33G Federal 9/16" x 5 15/32"










Chair Rails

	V29RTO Ribbon & Ivy 1 5/16" x 3 1/4"		OML43G Colonial 9/16" x 1 25/32"
	V18RMO Georgian 2 1/32" x 1 9/32"		V19RMO Versailles 2 7/32" x 1 15/16"
	V168GRO Georgian 1 9/32" x 1"		V149RMO Georgian 2 7/32" x 1 9/32"
	V20RMO Georgian 2 9/32" x 1 21/32"		

Panel Mouldings

	V18RMO Georgian 2 1/32" x 1 9/32"		V19RMO Versailles 2 7/32" x 1 15/16"
	V168GRO Georgian 1 9/32" x 1"		V149RMO Georgian 2 7/32" x 1 9/32"
	V20RMO Georgian 2 9/32" x 1 21/32"		

Casings

	OML14G Colonial 5/8" x 2 25/32"		OML18G Victorian 1 1/16" x 3 1/32"
	OML15G Colonial 1 1/4" x 3 1/4"		OML19G Victorian 1 1/16" x 4 1/32"
	OML16AG Tudor 3/8" x 2 3/4"		807G Fluted/Victorian 1 1/16" x 4"
	OML16G Tudor 2 1/32" x 3 1/4"		OML13G Georgian 1 1/16" x 3 1/2"
	OML16BG Tudor/Backband 2 9/32" x 1 3/16"		

Barbour House

Including both embossed and plain milled profiles, *Barbour House* Mouldings encourages creativity in the use of accents and built-up mouldings, especially cornices. If you want the very best, you want *Barbour House* Mouldings, from Ornamental Mouldings.



Mouldings

Authentic recreations of the most significant Period Styles in American architecture: Tudor, Colonial, Georgian, Federal and Victorian.

Period Recreations by...



Shown with antique finish.

OML34G
Colonial
+
V5022D
Versailles



OML37G
Dentil
+
OML26G
Tudor



Shown with antique finish.

V28RTO
Ribbon
& Ivy
+
OML30AG
Victorian



Shown with antique finish.

V5026D
Versailles
+
OML26G
Tudor



Shown with antique finish.

V28RTO
Ribbon
& Ivy
4" space
+
V29RTO
Ribbon
& Ivy



Shown with antique finish.

V5026D
Versailles
6" space
+
V19RMO
Versailles